

QUICK REFERENCE GUIDE

Optional Shocks*

Model	Year	Height	P/N	Note	Price	Front	Rear
CHEVY/GMC							
Pickup 1500	07-16	2"	C1200		\$69.95	n/a	4719
	99-06	2"	C1201		\$99.95	4612	4719
	88-98	2"	C1201		\$99.95	4601	4608
2500HD/3500	11-16	2"	C1204	1	\$99.95	7603	
Pickup 2500HD 4WD Critical Information: See Note #4	01-10	2"	C1202/ C1203	2, 4	\$99.95	4615	4757
Pickup 3500HD 4WD Critical Information: See Note #4	01-10	2"	C1202/ C1203	2, 4	\$99.95	4615	4757
Avalanche/Tahoe/Yukon/ Suburban	07-14	2"	C1200		\$69.95	n/a	4719
	00-06	2"	C1201		\$99.95	4612	4719
Colorado/Canyon	15-16	1.25"	C1121		\$49.95	n/a	n/a
	04-12	2"	C1214		\$99.95	n/a	4607



D1200

**Most Affordable
& Easy To Install**

DODGE							
Ram 1500 4WD	12-16	2"	D49	6	\$519.95		
	06-11	2.5"	D48	6,7,8	\$595.99		
	02-05	2"	D1200	3	\$99.95		
	94-01	2.5"	D1251		\$99.95	4700	4719
Ram 2500	14-16	2"	D1201		\$99.95	4713	4759
Ram 3500	13-16	2"				4710	4700
Ram 2500/3500 4WD (Including MegaCab)	03-12	2.5"	D1251	5	\$99.95	4700	4759
Ram 2500/3500 4WD	94-02	2.5"	D1251		\$99.95	4700	4719



D1251

FORD							
F150	09-16	2"	F1203		\$99.95	n/a	4650
	04-08	2"	F1200		\$81.95	n/a	4650
	97-03	2"	F1202		\$99.95	4805	4850
F250/F350 4WD SuperDuty	05-16	2"	F1201		\$99.99	4710	4760
		1"	F1101		\$69.99	4710	4760
	99-04	2.5"	F4		\$295.95	4620	4760
		1"	F5101		\$74.95	4620	4760
Excursion	00-05	1"	F5101		\$74.95	4620	4762
Expedition	98-02	2"	F1202		\$99.95	4805	



F5101

HUMMER							
H3 & H3T	05-10	2"	C1215		\$99.95	n/a	n/a

TOYOTA							
Tundra 4WD	07-16	3"	T1300		\$99.95	n/a	4700
Tacoma 4WD	05-12	2.5"	T1251		\$99.95	n/a	4809



T1300

This is a quick reference guide. For complete kit details see actual application pages.

*** For Nitro Shocks change "4" to "7". For example: 4615 becomes 7615 for Nitro.**

Notes

- Requires front shock extension kit (pn: CS202) or Zone shock #7603.
- Requires front shock extension kit (pn: CS201) or Zone shock #4615/7615
- Shock extension kit D5201 recommended
- To determine whether a C1202 or C1203 kit is required, verify which RPO codes are shown in the glove box to determine the factory installed torsion keys.
Any of the following RPO codes require the C1202 kit: FT2 - FT3 - FT4 - FT5 - FT6 - FT7
Any of the following RPO codes require the C1203 kit: FK2 - FK3 - FF6 - FF7 - FF8 - FF9
- Will not fit PowerWagon models due to the factory 2" lift.
- Not recommended for use with Bilstein leveling struts, or with any other form of suspension lift.
- Included preload spacer will not be used on 2009 and newer TRX models
- Do Not install spacer kit without upper control arms, the factory upper ball joint will be extended past operating range. Vehicle damage may occur.